



How to Configure Video Recording on DS-K1T502

| | | | | | |
|-----------------|---|-----------------|------|--------------|------------|
| Title: | How to Configure Video Recording on DS-K1T502 | Version: | v1.0 | Date: | 02/15/2023 |
| Product: | Access control | | | Page: | 1 of 3 |

Preparation

1. TF Card. Max. 256G supported
2. DS-K1T502 Series

How to Configure Video Recording on DS-K1T502


1. Install TF Card

- 1) Install TF Card and back cover before power on device. If you install TF card when device is powered on, please reboot device




2. Configure Event Linkage

- 1) Log in device web page.




| | | | | | |
|-----------------|---|-----------------|--------------|--------------|------------|
| Title: | How to Configure Video Recording on DS-K1T502 | Version: | v1.0 | Date: | 02/15/2023 |
| Product: | Access control | | Page: | 2 of 3 | |

- Go to configuration->Event->Event Detection-> Linkage Settings, click Add, then you can add new event and card linkage. Set trigger event according to your actual need, here we take door open event for example




- Click General Linkage Settings to set recording time and recording delay. Then linkage setting is finished.




3. Check recording video

- Go to Event Search, you can select 'View event with recorded video' option to search for video.

| | | | | | |
|-----------------|---|-----------------|------|--------------|------------|
| Title: | How to Configure Video Recording on DS-K1T502 | Version: | v1.0 | Date: | 02/15/2023 |
| Product: | Access control | | | Page: | 3 of 3 |



2) Click the 'play' icon at the end of event , you can check recorded video





See Far, Go Further